## PCP WEATHER PROTECTION COVER INSTRUCTION OF USE

1. Take the cover out of the package. The PCP Weather Protection Cover will consist of 1 piece. See Fig.1




Fig 1

2. Place the cover over the PCP and use the retaining hooks to secure to the rear of the PCP. See Fig's 2 & 3



Fig 2 Fig 3

3. Once the retaining hooks are secured you can now fully open the PCP door and extend the sheet forward and using the hand clamps shown below (Fig. 4) (blue arrow) clamp to the top of the PCP door. In addition there is also an elastic cord which is runs under the PCP door. Fig 5 (green arrow)



If required a sandbag can be used on the skirting to hold in place in windy conditions. See Fig 5 (yellow arrow).

\*Please note this item will fit all PCP's and with smaller units, as per the below you would need to use a panel barrier as a fixing point for one side see Fig 6



Fig 6

4. When removing the cover, release the clamps, remove the securing hooks at the rear and elastic cords on the door first then place flat on the floor folding into a rough square and pack in to the bag supplied. The bag is oversized to allow for easy fit. (Fig. 7 & 8)



Fig 7 Fig 8