


## User Manual For C00-6119 (1mW) & C00-6118 (10mW) Visual Fault Locators

### Visual Fault Locator



#### Detailed parameter

Wave output	650nm
Fibre connector	universal-connector
Operating temp.	0~+60。
Store temp.	-20~+70。
Battery style	LR6 AA 1.5V*2
Battery life	>40H (1mW)
Size	175mm*26mm*26mm
Weight	170g

Please properly install the batteries. Switch in middle for power off, switch up for CW output, switch down for flashing output .

**CAUTION: IMPROPER OPERATION WILL CAUSE DAMAGE TO THE DEVICE! ALWAYS MAKE SURE:**

1. You use a good quality fibre pigtail or patch cord with well poished clean end faces
2. Always VERTICALLY insert and pull out the connector of the fibre. Otherwise, the ceramic tube may become broken.